

Do web prehliadaču (IE,Edge,Chrome,Firefox) zadajte:

192.168.1.1 alebo **192.168.0.1**




Is the "Caps Lock" enabled on your keyboard?

The username and password must be lowercase, please ensure that the "Caps Lock" LED is disabled on your keyboard and try again.

Forgot your username or password?

Please reset this device to the factory default settings if you have forgotten your username or password. The default username and password are both set to "admin".

Alebo



TP-LINK®

- Status
- Quick Setup
- WPS
- Network
- Wireless
- DHCP**
- DHCP Settings
- DHCP Client List
- Address Reservation
- Forwarding
- Security
- Parental Control
- Access Control
- Advanced Routing
- Bandwidth Control
- IP & MAC Binding
- Dynamic DNS
- System Tools

Kliknite na DHCP / DHCP Settings

DHCP Server: Disable Enable

Start IP Address:

End IP Address:

Address Lease Time: minutes (1~2880 minutes, the default value is 120)

Default Gateway: (Optional)

Default Domain: (Optional)

Primary DNS: (Optional)

Secondary DNS: (Optional)

Save

TP-LINK®

- Status
- Quick Setup
- WPS
- Network
- Wireless
- DHCP**
- DHCP Settings
- DHCP Client List
- Address Reservation
- Forwarding
- Security
- Parental Control
- Access Control
- Advanced Routing
- Bandwidth Control
- IP & MAC Binding
- Dynamic DNS
- System Tools

DHCP Settings

DHCP Server: Disable Enable

Start IP Address:

End IP Address:

Address Lease Time: minutes (1~2880 minutes, the default value is 120)

Default Gateway: (Optional)

Default Domain: (Optional)

Primary DNS: (Optional)

Secondary DNS: (Optional)

Save

Kliknite na Save

Nastavte:

Primary DNS: **172.21.21.10**

Secondary DNS: **8.8.8.8**

← → ↻ ▲ Nebezpečné | 192.168.1.1

Kliknite na OK

Správa z webu 192.168.1.1

Note: The change of DHCP config will not take effect until this device reboots!

TP-LINK®

DHCP Settings

DHCP Server: Disable Enable

Start IP Address:

End IP Address:

Address Lease Time: minutes (1~2880 minutes, the default value is 120)

Default Gateway: (Optional)

Default Domain: (Optional)

Primary DNS: (Optional)

Secondary DNS: (Optional)

Status

Quick Setup

WPS

Network

Wireless

DHCP

- DHCP Settings

- DHCP Client List

- Address Reservation

Forwarding

Security

Parental Control

Access Control

Advanced Routing

Bandwidth Control

IP & MAC Binding

Dynamic DNS

System Tools

TP-LINK®

DHCP Settings

DHCP Server: Disable Enable

Start IP Address:

End IP Address:

Address Lease Time: minutes (1~2880 minutes, the default value is 120)

Default Gateway: (Optional)

Default Domain: (Optional)

Primary DNS: (Optional)

Secondary DNS: (Optional)

The change of DHCP config will not take effect until this device reboots, please [click here](#) to reboot.

Aby sa prejavili zmeny ktoré ste urobili, musí sa wifi router restartnúť. Kliknite na **click here**.

Status

Quick Setup

WPS

Network

Wireless

DHCP

- DHCP Settings

- DHCP Client List

- Address Reservation

Forwarding

Security

Parental Control

Access Control

Advanced Routing

Bandwidth Control

IP & MAC Binding

Dynamic DNS

System Tools

- Status
- Quick Setup
- WPS
- Network
- Wireless
- DHCP
- DHCP Settings
- DHCP Client List
- Address Reservation
- Forwarding
- Security
- Parental Control
- Access Control
- Advanced Routing
- Bandwidth Control
- IP & MAC Binding
- Dynamic DNS
- System Tools

Reboot

Click this button to reboot this device.

Reboot

Kliknite na **Reboot**

- Status
- Quick Setup
- WPS
- Network
- Wireless
- DHCP**
- DHCP Settings
- DHCP Client List
- Address Reservation
- Forwarding
- Security
- Parental Control
- Access Control
- Advanced Routing
- Bandwidth Control
- IP & MAC Binding
- Dynamic DNS
- System Tools

Restart

Restarting...



Počkajte kým sa wifi router reštartne.

Po reštarte by už **youtube.com** malo fungovať !!!